Installing Larger Orifice Hardware Kit into Water Valve of Electric ⁵⁴³⁰⁰⁹⁶⁸ & Insulated Drinkers

For questions about this product, or for parts inquiries, please contact our Customer Service Center listed below.


<u>STEP 1</u>

Remove the packaging tape from around the top of the valve.



<u>STEP 2</u>

Slide off cover, pivot upper arm up and remove the plunger.



STEP 3

Using either a 5/16" wrench or 5/16" socket, remove all four of the screws. Then separate the front of valve from the back.



STEP 4

With the back piece of the valve (containing the small orifice), use a 4.5mm hex key (Allen Wrench) to remove the small orifice.

NOTE: Turn wrench to the left to loosen the orifice.



Small Orifice



<u>STEP 5</u>

STEP 6

Clean the hole of any obstruction before placing the large orifice in the valve.

It is suggested to use pipe sealant when installing the orifice.

Use the 3/8" hex key to

install the large orifice

in the valve. Tighten to

NOTE: Turn the hex key to the right to tighten.

a snug fit, but do not





Large Orifice

<u>STEP 7</u>


over tighten.

Replace the front cover of the valve with the four screws that hold it together.

<u>STEP 8</u>

Replace the plunger with the nipple facing – you and the rubber facing the valve.






STEP 9 Replace the cover _

installation.

to complete the



CUSTOMER SERVICE CENTER

PO Box 569 Columbus, NE 68602-0569 Ph: 800-447-2751 Fax: (402) 563-7447 www.behlencountry.com

TECHNICAL INFORMATION 70111